

Réglage de la minuterie

Tournez les boutons pour définir:

Temps "ON" de 1 à 60 minutes.

Temps "OFF" de 5 minutes à 12 heures.

Sélection du mode de fonctionnement

Poussez l'interrupteur pour sélectionner:

"Day" : la sortie est activée uniquement pendant la journée.

24 h : la sortie est activée jour et nuit.

"Night" : la sortie est activée uniquement pendant la nuit.

Le **capteur de lumière** sert de détecteur jour / nuit.

L'indicateur **OUTPUT** est allumé lorsque le cordon de sortie (ou cordon d'alimentation) est mis sous tension.

Pour le service à la clientèle et la garantie
visitez www.gardencontrols.com
ou contactez-nous au
(855) 262-1800 ou à info@gardencontrols.com

USER GUIDE

CYCLE TIMER


GARDEN CONTROLS

The **CYCLE TIMER** controls any 120V equipment such as irrigation pumps, fogger, fans or CO₂ generators on periodic cycles. The output is repeatedly turned ON and OFF for periods corresponding to the ON and OFF times.

Plug equipment into output cord (piggy back cord).

The **OUTPUT** indicator is lit only when power is supplied to the output.

Specifications :
Load: 120V 12A
5-ft Piggy Back Cord.



Setting your times

Simply rotate the knobs to set:
ON Time from 1 to 60 minutes.
OFF Time from 5 minutes to 12 hours.

Selecting the operating mode

Simply slide the switch to select:

- Day** : the output is activated during the day only.
- 24 h** : the output is activated day and night.
- Night** : the output is activated during the night only.

The **LIGHT SENSOR** serves as the day/night detector.

The **OUTPUT** indicator is lit when power is applied to output cord (piggy back cord).



GUIDE D'UTILISATION **GARDEN CONTROLS**

MINUTERIE PÉRIODIQUE

Le **CYCLE TIMER** contrôle tous les équipements 120V tels que les pompes d'irrigation, les humidificateurs, les ventilateurs ou les générateurs de CO2 en cycles périodiques.

La sortie est activée et désactivée de manière répétée pour les périodes correspondant aux temps d'activation (**ON**) et de désactivation (**OFF**).

Branchez l'équipement dans la **prise de sortie** du cordon d'alimentation.

L'indicateur **OUTPUT** est allumé lorsque le cordon de sortie (ou cordon d'alimentation) est mis sous tension.



For Warranty & Customer Service
Please visit www.gardencontrols.com
or contact us at
(855) 262-1800 or at info@gardencontrols.com

Caractéristiques :
Charge : 120V 12A
5 pieds de cordon d'alimentation.